



LOAD



UNLOAD



LOAD

Comandi (OUT)

Start

Unlock

Lock

Vacuum

Air

Oil

Air2

Close_cicle

Segnali di stato (IN)

Alarm


Ready_to_unlock

Ready_to_lock

Out_of_Mic

Vacuum_High

Vaccum_Low



UNLOAD

Comandi (OUT)

Start

Unlock

Lock

Vacuum

Air

Oil

Air2

Close_cicle

Segnali di stato (IN)

Alarm

Ready_to_unlock

Ready_to_lock

Out_of_Mic

Vacuum_High

Vaccum_Low

